

Builders Best Recessed Can Downlight Retrofit Kit Installation Instructions

Congratulations! You've purchased a Builders Best Professional Grade Recessed Can Down Light RetroFit Kit. Your kit includes everything you need to change an existing fixture into a permanent, money-saving compact fluorescent light fixture in minutes. Here's how it works:

1. Turn off power to the fixture.
2. Remove old bulb from socket.
3. If socket plate is adjustable, loosen fasteners and push plate to top of can and tighten (Diagram 1).
4. Screw socket adapter into socket (Diagram 2).
5. Snap on ballast wiring connector to socket adapter (Diagram 3a).
6. Insert reflector/ballast assembly into recessed can by sliding the spring hangers through the recessed can brackets (Diagrams 3 & 4).
7. If fixture does not fit all the way inside, remove fixture, snap socket out of the socket plate, remove socket plate and move socket to the side of fixture while repeating step 6.
8. Replace outer trim and snap on diffuser cover, if desired (Diagram 4).

Recessed Can Downlight Retrofit Kit Components

